


Digi-Dry

Digital Print Dryer

Dual Stand Assembly Instructions:

1. Remove hardware shown from upright.
2. Rotate upright to vertical position & align the hole in the upright with the slot in the base plate.
3. Re-install hardware thru base plate into the upright as shown with the larger washer on the same side as carriage bolt & base plate.
4. Tighten adjustment knob.
5. Repeat steps 1-4 on opposing side.
6. Install heater head per Digital Dryer Assembly Instructions.



BBC INDUSTRIES INC.

5 Carper Drive
Pacife, MD 63069 USA
(636)343-5800 FAX: (636)343-3932
WWW.BBCIND.COM